



No.	Carefree Part No.	Coast Part No.	Description
6	901020	200-34200	Carefree BLACK car port foot for main inner arm
	901020W	200-34070	Carefree WHITE car port foot for main inner arm
7	901046W	200-34040	Carefree hardware remote lock WHITE - length: 38.5" (97.8cm)
	901046	200-34214	Carefree hardware remote lock BLACK - length: 38.5" (97.8cm)
8	901017	200-34202	Carefree BLACK travel lock
	901017W	200-34050	Carefree WHITE travel lock
9	901015W	200-34060	Carefree WHITE lift handle
	901015	200-34204	Carefree BLACK lift handle
12	R00405	200-34090	Carefree brace slider assembly
13	901022	200-34120	Carefree pair of BLACK locking knob with nut
14	902801W	200-34130	Carefree pair of WHITE canopy clamps
15	901019W	200-34080	Carefree WHITE bottom bracket
	901019	200-34206	Carefree BLACK bottom bracket

18	901018W	200-34140	Carefree WHITE top bracket
	901018	200-34208	Carefree BLACK top bracket
20	R00925WHT	200-34032	Carefree WHITE spring assembly cam end for 8'to18' awning (r/hand)
	R00925BLK	200-34212	Carefree BLACK spring assembly cam end for 8'to18' awning (r/hand)
	R00926WHT	200-34036	Carefree spring assembly cam end 18' to 21' awning (r/hand)
21	R00923WHT	200-34030	Carefree WHITE spring assembly non cam end for 8'to18' awning (l/hand)
	R00923BLK	200-34210	Carefree BLACK spring assembly non cam end for 8'to18' awning (l/hand)
	R00924WHT	200-34034	Carefree spring assembly non cam end 18'to21' awning (l/hand)
25	R022406-001	200-34160	Pull down strap for Carefree Fiesta awning
	030573	200-34194	Carefree Screw 1/4" 20UNC x 1/4" LG S/Steel
	R030345-007-MP	200-34196	Carefree Semi Tube Rivet
	901035	200-34170	Carefree Pull Down Wand

Note: Awning 7'11" and shorter use only x1 R/Hand Spring i.e. there is no L/Hand Spring